


# Fisher-Price®

Instructions

## 1-2-3 Roller Skates



Please keep these instructions for future reference.

For ages 2-6, shoe sizes 6-12.

1-2-3 Roller Skates have been designed to be worn on either foot.

Use your 1-2-3 Roller Skates indoors and outdoors.

### Message to Parents

Learning to skate is as easy as 1-2-3 with Fisher-Price 1-2-3 Roller Skates! With their three-way wheel control, they make learning a breeze and provide hours of fun and exercise. Take a moment to review these safety tips and instructions so your child knows how to use the 1-2-3 Roller Skates safely and correctly.


### Safety Tips

- Wear a helmet, knee pads and elbow protectors to guard against bumps and bruises.
- Supervise beginner skaters. It helps to hold the beginner's hand and to guide the beginner along a smooth, level surface.
- Wear shoes or sneakers, not open-toe shoes.
- Keep loose laces and pant legs away from the wheels.
- Select areas for skating which are free from obstacles.
- Avoid skating on streets, roadways and driveways which enter vehicle traffic routes.
- Never hitch a ride behind a bicycle or car.

### WARNING

Protective equipment should be worn.


## Wheel Control Adjustment




- Locate the wheel control plate on the underside of the skate.
- **Press down** and slide the wheel control plate to:
  - 1 Full Stop**
    - The front wheels lock so your skater can walk on the skates to get used to them.
  - 2 Forward Only**
    - Your skater can roll forward but the front wheels lock to prevent rolling backward.
  - 3 Free Wheeling**
    - Your skater rolls forward and backward unrestricted.

**Please Note:** Check to be sure both skates are set to the same wheel control position. Before fitting the skates on your child, test the skates on a flat surface.


## Fitting the 1-2-3 Roller Skates



- Turn the skate upside down.
- Squeeze the size adjustment buttons together, while pulling the front of the skate to the fully extended position.
- Repeat this procedure to open the other skate to the fully extended position.



- Make sure your child is seated.
- Place your child's foot in the skate.
- Squeeze the size adjustment buttons together, while pushing the front of the skate to the appropriate size for your child.
- Repeat this procedure to adjust the size of the other skate to your child's other foot.



- Insert the fastener strap into the slot on the side of the skate.
- Pull the fastener strap tight and fold it back on itself to secure.



Questions? We'd like to hear from you!

Call Fisher-Price Consumer Affairs, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price Consumer Affairs, 636 Girard Avenue, East Aurora, New York 14052.

If you have any questions about this product:

**In Canada**, call **1-800-567-7724**, or write to: Mattel/Fisher-Price, 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

**In Great Britain**, telephone 01734 770488.

**In Australia**, call the Fisher-Price Australian Consumer Advisory Service toll-free at 1-800-800-812, or write to: Fisher-Price, Mattel Pty. Limited, 461 Plummer Street, Port Melbourne, Victoria 3207.