


CAR WASH

Move vehicle through car wash.




TURNTABLE

Turn vehicle around in tune-up center.


REPLACE BATTERIES

Batteries should be changed when the robot voice sounds scratchy or intermittent and cannot be understood.

Remove screw and battery cover (located underneath base of playset).



Install three "AA" size batteries as shown. Replace battery cover and screw.



• This product is not recommended for use on loose dirt or wet surfaces.

ALKALINE BATTERIES RECOMMENDED:

For longer life use only alkaline batteries.

BATTERY SAFETY INFORMATION:

- 1. Non-rechargeable batteries are not to be recharged.
- 2. Rechargeable batteries are to be removed from the toy before being recharged.
- 3. Rechargeable batteries are only to be charged under adult supervision.
- 4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- 5. Do not mix old and new batteries.
- 6. Only batteries of the same or equivalent type as recommended are to be used.
- 7. Batteries are to be inserted with the correct polarity.
- 8. Exhausted batteries are to be removed from the toy.
- 9. The supply terminals are not to be short-circuited.
- 10. Dispose of batteries safely. Do not dispose of in a fire as the batteries may explode or leak.
- 11. Products with non-replaceable batteries are not to be disposed of in a fire as the batteries inside may explode or leak.

2-YEAR LIMITED WARRANTY

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052 for replacement or refund at our option. This warranty does not cover damage resulting from unauthorized modification, accident, misuse, or abuse. In no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). Valid only in U.S.A. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you.

Send only the product to the address above. Send all correspondence to Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, California 90245-5012, U.S.A.

Or you may phone us toll-free at 1-800-524-TOYS, Monday— Friday, 8:00 a.m.—6:00 p.m. Eastern Time. Outside U.S.A., see telephone directory for Mattel listing. VOU CAN TELL IT'S MATTEL!** Call us toll-free or write with any comments or questions about our products or service. Monday-Friday, 8:00 a m-6:00 pm. Eastern Time. Outside U.S.A. see telephone directory for Mattel listing. Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A.

1 (800) 524-TOYS

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

We are dedicated to quality products.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303.

Mattel Australia Pty. Ltd., Richmond, Victoria 3121.

Consumer Advisory Service 1800 800 812 (valid only in Australia).




CONTENTS:

Batteries included are for demonstration purposes only. Includes 3 "AA" size batteries. Requires 2 "D" batteries, not included.

⚠ WARNING:


CHOKING HAZARD – Small parts.


Not for children under 3 years





© 2001 Mattel, Inc. El Segundo, CA 90245 U.S.A. All Rights Reserved.


as they contain important information.













8. ADD COMPOUND TO PLAYSET



Remove wrapping from container. Remove lid and pour compound into playset as shown. When finished playing, return compound to original container and close lid tightly.



- The compound may stain or stick to some surfaces. Protect play area before use.
- To remove stains, hand-wash with laundry detergent and warm water.
- SAFETY TESTED.
- GENTLE.

