

TYCO®




Baby Play Gym

INSTRUCTION SHEET


IMPORTANT: Before assembling your Baby Play Gym please note there are two pairs of Leg Supports, one pair is different from the other pair.

Step ①




- A. Match the pair of Leg Supports and line up the Crossbar between these two legs as shown in the figure.
 - B. Firmly push the ends of the Crossbar into the connections on each leg until the buttons snap into the holes.
 - C. Assemble the other pair of Leg Supports in the same way, as described above.
- Note:** Crossbar connections should face inward toward each other.

Step ②



- A. Insert both assembled Leg Support units into the Main Support Bar as shown in the figure.
- Note:** Legs should angle outwards when attached to the Main Support Bar.

Step ③




The Detachable Rings (as shown in the figure), are designed so that you can hang the Characters and Activities on the Play Gym.

- A. Squeeze the Ring ends together and push the Locking Pin outwards from the small loop to unlock the Ring. To lock the Ring, push the Locking Pin back into the loop.
- B. Hang the Characters and Activities to the Main Support Bar and the Crossbars using the Detachable Rings, as shown on the outside of the box or any way you wish.

Note: The Characters and Activities are designed so that they can even be detached from the Gym and hung on your child's crib or playpen.

Step ④



- A. Attach the three detachable shapes to the Shape Holder.
- B. Insert the open ends of the shapes up onto the holes until they lock in place.