


IMPORTANT! BEFORE USING:



- Turn the projector on without a reel in place.
- Point the projector at a white wall or surface to help determine bulb brightness.
- Turn the keyhole until you have the brightest light with minimum dark spots.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, New York 14052, U.S.A.
©2000 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.
View-Master® is a U.S. trademark of Mattel, Inc.

Printed in China

www.view-master.com

73889pr-0921