







## HELPFUL HINTS

- **ONE-TIME SNAPS:** Assembly steps that are marked with a star (★) are "one-time snaps." Once these parts are put together, they cannot be taken apart.
- For best performance, assemble on a hard, flat surface or low-pile carpet.

## ASSEMBLY



Configure the base of the playset anyway you choose.




Tools can be stored in any of the hex pieces.

1



Connect the  handle to the mold-press.


2



Place the mold-press garage over any opening on a base piece.



## ASSEMBLY



Tiny the Crane rotates 360 degrees.

## HOW TO MOLD (TINY THE CRANE)

1




Open Tiny's mold, press Playsand into the opening and close.


2



Press down and release.



Press Playsand into any of the molds and remove.



Open the wrecking ball, press Playsand into mold, and remove sand I-beam.



## HOW TO MOLD (MOLD-PRESS GARAGE)

1




Press Playsand into mold tray and place tray onto sliding platform.

2



Slide the tray into the mold-press.

3



Press down on the mold stamper and release.


4



Slide the tray out and remove Playsand molds.



## HOW TO MOLD [TOOLS]



For best performance, place Playsand on a hard, flat surface.



Press the roller over the Playsand and roll to create tool molds.




Use the saw to chop the Playsand. Press Playsand into handle to create hazard stripe molds.



Use the hammer to flatten the Playsand and create different textures.



Scoop or press Playsand into the shovel to mold.



Press Playsand into the bottom of Bob's Yard gate to mold or use the gate to rake the Playsand.



## HOW TO MOLD (DIZZY)



Press Playsand into Dizzy's mixer to make a construction barrel.

## HOW TO MOLD (WENDY/BOB STAMPER)



Place Playsand on a hard, flat surface and press the stamper to create boot prints.


## HOW TO DEMOLISH

### Wrecking Ball



Rotate Tiny the Crane to swing the wrecking ball.

### TNT Demo Pad



Quickly press down on the TNT box to make the demo pad rise.

Store Mash & Mold playsand in the provided bag after use.

Mash & Mold playsand is susceptible to environmental factors such as humidity and water. If sand gets wet, allow it to air dry until normal texture returns.

This product may stain or stick to some surfaces such as carpeting or upholstery. Protect play surfaces before use.



©2015 HIT Entertainment Limited and Keith Chapman.  
The Bob the Builder name and character, related characters and logo are trademarks of HIT Entertainment Limited.  
©2015 HIT Entertainment Limited.  
HIT and the HIT logo are trademarks of HIT Entertainment Limited.

©2015 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. **PRINTED IN CHINA.**

Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500.

DMM55

For videos, activities and more, visit:  
**WWW.BOBTHEBUILDER.COM**

**Fisher-Price®**  
fisher-price.com



DMM55-0970  
1101076470-DOM

**CONSUMER ASSISTANCE**  
1-800-432-5437 (US & Canada)  
1300 135 312 (Australia)  
**service.fisher-price.com**

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.  
Hearing-impaired consumers: 1-800-382-7470.

#### Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB, Helpline: 01628 500303, www.service.mattel.com/uk

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.