



2. ASSEMBLY


1A.




1B. Attach the ropes starting from the bottom turnbuckles up.




2.





3.





4. Slide down Cage 'C'-clip side first.





5.



6.





7.





3. TO PLAY

1. Slide **POWER SWITCH** to **ON (I)**. **BELL** will sound and crowd cheering will start.




- 2A.** Face a Tough Talkers™ figure (not included) towards the Ring's IR BOX. Push the **BUTTON** on figure to register. After a few seconds, Superstar's entrance music plays.

HINT: New figures cannot be registered while entrance music is playing. Press IR box button to skip forward and register a second figure.



- 2B.** Register another Tough Talkers™ figure.

NOTE: **FIRST** figure registered is the Challenger. **SECOND** figure registered is the Champion (announced as "Opponent").




3. TO PLAY (CONTD.)

- 3.** The type of title match and the Superstars are announced. Pull championship or press button on IR BOX when type of title is announced to change title match-type.

NOTE: Figures cannot recognize other figures that are currently talking. Wait until phrases are complete before pressing figure's button again.


Match Type:

WWE® World Heavyweight Championship
United States Championship
Intercontinental Championship
Universal Championship
Tag Team Championship



- 4.** MATCH starts when the BELL rings. RING plays crowd and fight sounds during the match. Press button on FIGURES to activate Superstar sounds and phrases.


NOTE: If at any time during play, a figure faces away from the Ring's IR BOX, the figure will not be recognized. Simply reface the figure towards the center of the ring for instant recognition.




- 5.** Pull down championship to end match and start the three count! The figure whose button was pushed the most wins! Challenger wins if neither figure was activated.

NOTE: Match will end automatically after 3 minutes if no figure's button is pressed. Press button on FIGURES to continue the match.

During play, you can press the TOP or BOTTOM IR box button at anytime to advance the play sequence.




6. Press the TOP or BOTTOM IR box button to restart the match.



To preserve battery life, RING will automatically power OFF when left idle for a few minutes. Press IR box buttons or pull championship to reactivate.

TAG TEAM CRASH CAGE MATCH


Lock additional figures in the cage! Push buttons to drop to the ring!




4. THREE MORE WAYS TO PLAY

1. Add additional Tough Talkers™ figures (not included) DURING the match! Register additional figures, ring will play their entrance music and signature phrases!

NOTE: Figures added during the match cannot win.




2. Fight a Tough Talkers™ figure with a standard WWE® figure. Register 1 Tough Talkers™ figure and press the IR box button or pull championship to start the match!




Standard WWE® figure not included, sold separately.

3. Fight 2 standard WWE® figures!
Press the IR box button or pull championship to start the match with WWE® sounds!



5. BATTERY INSTALLATION

- Batteries included are for demonstration purposes only.
- Replace the batteries if sounds distort.
- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Remove batteries and dispose of them safely.
- Install 3 new AA (LR6) batteries in the orientation (+/-) shown.
- Replace battery cover and tighten screw.
- For longer life, use alkaline batteries.
- When exposed to an electrostatic source, the product may malfunction.
To resume normal operation, remove and re-install the batteries.



BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.



Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.

©2017 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel South Africa (PTY) LTD, Office 102 B, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.

**FFH41-097061
1100225059-00M**

