

nickelodeon™



Magical Light-Up Genie Palace

Keep these instructions for future reference as they contain important information.

Need help assembling this product?
Go to service.fisher-price.com and enter FLV06.
Click on the product image and then click the video link for a step-by-step assembly video.



Helpful Hints

- ★ Assembly steps that are marked with a star (★) are "one-time snaps". Once these parts are put together, they cannot be taken apart.




ADULT ASSEMBLY REQUIRED.
REQUIRED TOOL: PHILLIPS SCREWDRIVER (NOT INCLUDED).

Before you play


1 Label Sheet/Placement

Helpful Hints: Lay palace on the ground for easy label application.



2 Rotate translucent bottle door to locate switch on back of palace.


3 Remove protective film from mirror and discard.




Need help assembling this product? Go to service.fisher-price.com and enter FLV06. Click on the product image and then click the video link for a step-by-step assembly video.

Assembly

- 1 Connect the base pieces.




- 2 Align and fasten one of the c-shaped pieces to the **back** of the base.




- 3 Rotate the translucent bottle door closed and snap the middle tower into the base.



- 4 Rotate the door open, then align and fasten the other c-shaped piece to the base.



- 5 Place the floor piece face down and, using both hands, snap the staircase into place.



- 6 Insert floor piece underneath the mirror until it snaps into place.



- 7 Snap the large balcony in the large floor piece.



Assembly

8 Slide the smaller floor piece in until it snaps into place.




9 Slide the teal floor pieces into the **left** side tower and door until they snap into place.




10 Slide the purple floor pieces into the **right** side tower and door until they snap into place.



11 Align the left door with the hinge on the left tower, then insert metal pin from the bottom of the hinge.



12 Align the right door with the hinge on the right tower, then insert metal pin from the bottom of the hinge.



13 Insert the left and right towers into the base until they snap into place.



14 Fasten the left tower to the middle tower.




Assembly


- 15 Insert the balcony pieces to the back of the side towers until they snap into place.



- 16 Insert the rainbow pieces into the gem until they snap into place.



- 17 Snap the large gem stone into the top of the middle tower. Align the rainbow pieces to the turrets.



- 18 Align and fasten the rainbow pieces to the turrets.



Completed assembled palace
(Front view)



How to Play

Helpful Hints

- To wake up, press any of the buttons (top gem, mirror or bottom floor) or rotate door open if it is closed.
- To preserve battery life, palace enters sleep mode if inactive for 2 minutes.
- Clap activation will not work in sleep mode.

1 Pegging the Gems



2 Buttons for lights & sounds



Tuck stairs inside before closing.

Clap Activation

Once awake, lights and sounds can be activated by clapping. For best performance, clapping within 50cm (19in) of the large gem is recommended.

Helpful Hint:


- If clap activation doesn't work, clap closer to the large gem or clap louder.
- Clap activation works while lights and sounds are **not** playing.
- If clap activation continues to malfunction or no longer operates, remove the batteries from the toy and replace them with fresh batteries.



Battery Information

BATTERY INSTALLATION:

- Unscrew and lift cover from the back of the center bottle (upper section when palace door is closed).
- Install batteries as indicated inside the battery compartment.
- For longer life use only alkaline batteries.
- If the product begins to malfunction, check the battery installation. You may need to reset the electronics by removing the batteries and reinstalling them.
- If the product continues to malfunction or no longer operates, remove the batteries from the toy and replace them with fresh batteries.
- Requires 3 "AA" (LR6) batteries. Not included.



**REQUIRED TOOL:
PHILLIPS SCREWDRIVER
(NOT INCLUDED).**

BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.


NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-3 (B)/NMB-3 (B)

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes : (1) il ne doit pas produire de brouillage et (2) il doit pouvoir tolérer tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre son fonctionnement.



CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)

service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:
Canada: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2: www.service.mattel.com.
Great Britain: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500303. www.service.mattel.com/uk
Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.
New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.
SOUTH AFRICA: Mattel South Africa (PTY) LTD, Office 102 B3, 30 Melrose Boulevard, Johannesburg 2196.

© 2017 Viacom International Inc.
All Rights Reserved. Nickelodeon, Shimmer and Shine and all related titles, logos and characters are trademarks of Viacom International Inc.

©2017 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. **PRINTED IN MEXICO.**
Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.
Tel.: (852) 3185-6500.



Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.

FLV06

FLV06-0970
1101611031-DOM

Fisher-Price®