




IMPORTANT!

If the scooter does not run, please check the following:

- ✓ Battery is fully charged (18 hours for first-time charge; 14 hours after each use).
- ✓ Brake is properly adjusted. Please refer to pages 10-11 in your Owner's Manual.

If your scooter still does not run, you will need to reset the scooter's electronics. Please follow these instructions:



- While pressing the release button on the scooter floor, lift the footboard from the scooter (1).
- Remove the battery from the battery compartment (2).
- **Unplug** the motor harness connector from the battery socket (2).
- Now, **replace** the motor harness connector back into the battery socket. Push firmly to make sure the motor harness connector is completely inserted into the battery (2).
- Fit the battery back into the battery compartment, as shown. At an angle, insert the front tab on the footboard into the slot in the scooter floor. Push down on the footboard to "**snap**" it into place (3).
- Test to see if the scooter runs. While lifting the back wheel off the ground, press the button throttle. The back wheel should spin.
- If the back wheel does **not** spin, please contact a Power Wheels® authorized service center. For the location of a authorized service center nearest you, please visit us on-line at www.powerwheels.com or call 1-800-348-0751.