

# Tips for Better Images!




## 1 Use Bright Light

Make sure there is a bright light source when taking indoor pictures. The light source (sun, lamp or window) should be above or facing your picture subject. Do not place your picture subject in front of the light source since the picture subject will look black on the screen.

## 2 Use Indoor/Outdoor Setting on Cartridge

Select *Indoor*  or *Outdoor*  by sliding the switch on the cartridge.

## 3 Adjust the Contrast

Touch  on the Pixter® tool menu with the stylus. Use the stylus to tap the contrast line on the screen toward the sun  to *brighten* the image or toward the moon  to *darken* the image on the screen.

## 4 Hold Still

Make sure the picture taker and the picture subject aren't moving. If your child is having trouble holding Pixter® steady with one hand, have your child sit down and rest elbows on his/her lap.

## 5 Proper Distance for Portrait Images

Center the picture subject on the screen. The picture subject should be no more than 8 feet away from the unit for portrait images.

*While your child can use Pixter® Digital Camera independently, we recommend that you first thoroughly read the instructions included.*

*Explain to your child how to use the camera and then practice taking pictures with your child.*