


INSTRUCTIONS



4+

HW UNSTOPPABLE TIGER SHARK™



HVIN: HGV87R (), HGV87T ()

Operating Frequency: 2420MHz - 2462MHz

Maximum radio frequency power transmitted:

 : -1.84dBm (0.65mW),  : -0.85dBm (0.82mW)

⚠ CAUTION:

Surfaces may become hot and cause burns if electronics get wet. To prevent entanglement, keep all hair away from moving parts.

Adult supervision is recommended when the vehicle is being operated.

Keep these instructions for future reference as they contain important information.

IMPORTANT: Please read all instructions before operating your vehicle.

The toy is only to be connected to Class II equipment bearing the symbol .

HOTWHEELS.COM

©2022 Mattel. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Limited, The Porter Building, 1 Brunel Way, Slough SL1 1FQ, UK. Mattel Australia Pty. Ltd., 658 Church St., Richmond, Victoria, 3121. Consumer Advisory Service - 1300 135 312. Mattel South Africa (PTY) LTD, Office 102 I3, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsinghsatui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Continental Asia Sdn Bhd. Level 19, Tower 3, Avenue 7, No. 8 Jalan Kerinchi, Bangsar South, 59200 Kuala Lumpur, Malaysia.




HGV87-0970-G2_DOM

1: CONTENTS




2: FEATURES



3: SET UP

A. REMOTE CONTROLLER BATTERY INSTALLATION

1. Unscrew the battery cover with a Phillips head screwdriver (not included).
2. Install 2 AA (LR6) 1.5V alkaline batteries (not included) with polarity (+/-) as shown inside the battery compartment. For longer life, use alkaline batteries.
3. Replace battery cover and tighten screw.
4. Replace batteries in the remote controller if the LED on the remote controller does not go on during play or if the vehicle does not respond well after a recharge.





3: SET UP (CONTD.)

B. CHARGING THE VEHICLE

The vehicle is powered by a permanently installed Lithium-ion (Li-ion) battery, and it must be fully charged before first use.

1. Slide the power switch to CHARGE (⚡).
2. Open the charge port cover.
3. Connect one end of the charge cord to the vehicle's charge port and plug the other end into a 5V/1000 mA USB charger (not included).
4. Charging will begin when the cord is connected. A red LED on the vehicle will light up as the vehicle is charging.
5. The red LED will turn green when the vehicle is fully charged. Unplug the charge cord when charging is complete. A full charge will usually take approximately 90 minutes. Charging time may vary.
6. Close the charge port cover.
7. Recharge the vehicle if the vehicle begins to run slowly or does not respond.

NOTE: Power switch must be in the CHARGE (⚡) position when charging the vehicle.






TIP: The battery will be hot after play. Wait at least 10 to 15 minutes until the battery cools down before recharging the vehicle.

C. PAIRING THE REMOTE CONTROLLER AND VEHICLE

1. Slide the power switch to ON (I) on the vehicle.
2. Press the stomp button or push the remote controller's driving control joystick forward/backward after switching on the vehicle.
3. Pairing is complete when the LED changes from flashing red to solid red on remote controller.

NOTE: If the vehicle does not respond to the remote controller after pairing, switch the vehicle off then back on to try pairing again or replace the batteries in the remote controller if the batteries are drained.



TIP: The vehicle will go into sleep mode if left idle for approximately 15 minutes to preserve battery life. To resume normal play, slide the vehicle's power switch to OFF then ON again, and then push the remote controller's driving control joystick forward/backward to pair the vehicle and remote controller.

D. STEERING ALIGNMENT

1. Check the vehicle's steering alignment before playing by driving it forward to see if it is driving straight.
2. If the vehicle automatically steers toward the right/left, press the alignment button in the opposite direction a few times until it runs in a straight line.




ALIGNMENT BUTTONS

4: HOW TO DRIVE

CHECKLIST

- Is the vehicle fully charged?
- Is the remote controller equipped with fresh batteries?
- Is the remote controller paired with the vehicle?
- Has the vehicle's steering been aligned?

CONTROLS




SKILL CHECK!

Remember, steering directions are flipped on the remote controller when you are driving backward!


NOTE: Operating range of the remote controller is up to 30 m (98 ft).

STUNTS

Stomp!





Chomp!




Wheelie!

1. Drive forward and backward in full speed to build momentum.




2. As the vehicle is going backwards, quickly push the driving control all the way up to do a wheelie!



3. Drive forward to keep the wheelie going!



Wheelie Spin!



FOR PRODUCT SOLD IN USA

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

5: CONSUMER INFORMATION

TIPS & HINTS – FOR ALL DRIVING ENVIRONMENTS



1. When your vehicle starts to lose power, it may lose functionality or performance. It's time for a recharge. For best performance, always start with a fully-charged battery. Your vehicle's running time may change depending on driving style and driving environment.
2. Radio interference can make your vehicle run poorly. Interference can be caused by other RC vehicles running on the same frequency, electrical wires, large buildings, CB radios, or other wireless gear. Try to stay away from these!
3. Point your remote controller up, and not down toward your vehicle. If your vehicle gets too far away, it won't work properly.
4. Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries from remote controller before storage.
5. Don't drive your vehicle in sand or through water or snow. Do not immerse in water. If your vehicle does get wet, wipe it with a towel and allow to dry completely overnight. If your remote controller is accidentally dropped in water, remove battery(ies) and allow your remote controller to air dry. Replace with fresh battery(ies) before operation.
6. When exposed to an electrostatic source, the remote controller and/or the vehicle may malfunction. To resume normal operation of the remote controller, remove the batteries and reinstall them after 5 seconds. To resume normal operation of the vehicle, turn the power OFF for 5 seconds, then turn it ON again.

SAFETY TIPS

- Play safely! Do not drive the vehicle in the street!
- DO NOT pick up the vehicle while in motion.
- Keep fingers, hair, and loose clothing away from the wheels while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries from the remote controller when not in use and switch the vehicle OFF before storage.

RECHARGEABLE BATTERY SAFETY INFORMATION

- Rechargeable batteries are only to be charged under adult supervision.
- Do not recharge battery if it is hot. Allow it to cool before recharging.
- Do not recharge a battery pack that shows leakage or corrosion.
- Do not disassemble the battery pack. The battery pack is a sealed rechargeable Li-ion battery pack.
- If the battery pack and/or charging port are wet, thoroughly dry before charging.
- Do not recharge non-rechargeable batteries.
- The Li-ion battery in the vehicle is not intended to be replaced or removed by consumers. Before disposal in the waste stream, the Li-ion battery must be removed by a qualified professional and disposed of separately according to local regulations on battery collection and recycling.
- Do not dispose of the batteries in a fire.

BATTERY SAFETY INFORMATION

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.



Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.