



Stretch your mind with other software titles for your Smart Cycle®!

Each sold separately and subject to availability.



© 2010 Viacom International Inc. All Rights Reserved. Nickelodeon, SpongeBob SquarePants and all related titles, logos and characters are trademarks of Viacom International Inc. Created by Stephen Hillenburg.



DC SUPER FRIENDS and all related characters and elements are trademarks of and © DC Comics.



WB SHIELD: TM & © Warner Bros. Entertainment Inc. (s10)

Disney • Pixar elements © 2010 Disney • Pixar

Shrek Forever After™ & © 2010 DreamWorks Animation L.L.C.

www.fisher-price.com

PRINTED IN CHINA

T6353pr-0920

Fisher-Price®

T6353

SMART CYCLE® Racer

PHYSICAL LEARNING ARCADE SYSTEM

THOMAS
& FRIENDS™



NOTICE ABOUT EPILEPSY AND SEIZURES

PLEASE READ THIS NOTICE BEFORE YOU OR YOUR CHILD USE ANY VIDEO GAME.

A very small portion of the population have a condition which may cause a momentary loss of consciousness when viewing certain kinds of flashing lights or patterns that are commonly present in our daily environment. This condition may cause seizures while watching some kinds of television pictures or playing certain video games. Players who have not had any previous seizures may nonetheless have an undetected epileptic condition.


If you or anyone in your family has experienced symptoms linked to an epileptic condition (e.g. a seizure or loss of awareness), consult your physician before playing video games. We recommend that parents observe their children while they play video games. If you or your child experience any of the following symptoms such as dizziness, altered vision, eye or muscle twitching, involuntary movements, loss of awareness, disorientation or convulsions, **DISCONTINUE USE IMMEDIATELY** and consult your physician.

Additionally, please follow these precautions whenever playing a video game:

- Do not sit or stand too close to the television screen. Play as far back from the screen as possible.
- Do not play if you are tired or need sleep.
- Always play in a well lit room.
- Be sure to take a 10-15 minute break every hour while playing.

GETTING STARTED


- Please keep these instructions for future reference, as they contain important information.




- Insert the game cartridge into the socket on top of the cycle. Push to be sure it's fully inserted.
- Turn your TV or VCR power **ON**.
- Slide the power switch on the cycle to **ON**!
- To find the picture on your TV screen, set your TV's or VCR's mode selector to **INPUT** or **VIDEO IN**.

Note: You can use this Smart Cycle® software with any Smart Cycle® model.

CYCLE CONTROLS



THE DEPOT



Choose a Train!

- Use the joystick to scroll through train choices.
- Press either handlebar button to make your selection.




BACK ON TRACK




Find the objects.

- Pedal the cycle to move down the train track. *The faster you pedal the faster you go!*
- Use the handlebar to steer.
- Collect all the objects shown in the upper left corner of the screen. Simply drive into them. Don't bump into the other objects.



Taking snap shots.

- Press the right handlebar button  to take snap shots.

Hint: You can only take snap shots in this (*Back on Track*) activity.




Off ramps

- Keep traveling down the track or head onto an off-ramp for other fun games and activities. Simply bear to the side of the tracks as you see one approaching.


Hint: If you miss your ramp, you can pedal in reverse to back up.



REALLY USEFUL ENGINE




Help Thomas repair the broken train track.

- Use the joystick to move the matching track piece.
 - Replace all the missing track pieces and Thomas drives to the next stop.
 - When you're finished with this activity, press the exit button  to return to the track. Pedal to the next activity.
- First, look at the type and position of the missing track piece. Then, use the joystick to scroll through matching train track pieces at the bottom of the screen.
 - Press the handlebar button to select a track piece.



WHIRLYBIRD



Help collect Percy's mail.

- Use the joystick to steer the helicopter and collect floating letters. Try to catch the numbers in the order shown at the top of the screen.
- Watch the time at the top of the screen.
- Try to avoid the planes and hot air balloons -- they'll slow you down!
- When you're finished with this activity, press the exit button to return to the track. Pedal to the next activity.



TIDMOUTH SHEDS




Learn how trains work!

- Press either handlebar button to randomly select an object on the screen. Listen and learn how the object is used.
- When you're finished with this activity, press the exit button to return to the track. Pedal to the next activity.



JAMES' MESSY DAY



Help James load his car.

- Use the joystick to move James up and down the track to catch the falling paint in his train car.
- As more paint colors fall, make sure James is catching the correct color of paint. Match the paint color to the train car.
- Don't let James get too messy. If the bar at the bottom of the screen fills up, James won't be able to work!
- When you're finished with this activity, press the exit button to return to the track. Pedal to the next activity.



THE BIG RACE



Pedal as fast as you can to the finish line!

- Use the joystick to choose 1 Player or 2 Player game. Press either handlebar button to select the game.



1 Player


- Pedal down the track as fast as you can to the finish line. Try to speed past the other characters. Get to the finish line first and *you win!*



2 Player

- Each player takes a turn. Pedal down the track as fast as you can to the finish line. Look at your time.
- Now it's time for *Player 2* to beat your time.
- The player with the fastest time wins.
- When you're finished with this activity, press the exit button (exit button icon) to return to the track. Pedal to the next activity.

DOWN AT BRENDHAM DOCKS



Help Cranky the Crane spell words.

- Use your joystick to find the correct letter.
- Press either handlebar button to select the letter Cranky the Crane needs to complete the word.
- When you're finished with this activity, press the exit button (exit button icon) to return to the track. Pedal to the next activity.



CELEBRATE




It's time for a party!

- Complete all the activities and you can return to the train station to celebrate with Sir Topham Hatt.
- When you're finished with this activity, press the exit button (exit button icon) to return to the track. Pedal to the next activity.




TRAVEL JOURNAL





See previous
snap shot

See next
snap shot

- Press the travel journal button . Then use the joystick and handlebar buttons to review and select a snap shot.





Stamp Tool Erase

- Next, use the joystick and handlebar buttons to select the stamp tool  to decorate your picture.
- Choose a stamp with the joystick and handlebar buttons and place it on the snap shot.
- Select the erase button  to clear the screen and decorate another picture.



THE MAP



- You can travel around the track and head onto an off-ramp to access activities or simply press the map button  to visit any of the activities around the course.

CARE

- Wipe with a clean cloth dampened with a mild soap and water solution. Do not immerse.
- This product has no consumer serviceable parts. Do not take this product apart.



- Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities (Europe only).

CONSUMER INFORMATION


CONSUMER ASSISTANCE
 1-800-432-5437 (US & Canada)
 1300 135 312 (Australia)


service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
 Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
 Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park,
 Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Mattel Europa, B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
 Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
 Albany 1331, Auckland.