



RIP-START CHALLENGE LOOP


INSTRUCTIONS

5+


CONTENTS



REFER TO LETTERS MOLDED ON TOY PARTS AND THROUGHOUT THE INSTRUCTIONS TO HELP WITH ASSEMBLY.



1 / APPLY LABELS



©2013 Mattel. All Rights Reserved.

Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Malaysia. Tel:03-78803817, Fax:03-78803867.

Corvette™; Plymouth Superbird™; Petty®

© Disney/Pixar

www.disney.com/cars


service.mattel.com

BFM23-0920G1




2 / ASSEMBLY


1



2




3







4

Slide to attach parts and move the loop marker to 2.
IMPORTANT: The loop marker and base marker must be set to the same number.




5




3 / TO PLAY

THE ROOKIE RACER JUMP

1 Load up to 4 vehicles (Additional vehicles not included).
Insert ripcord all the way through vehicles in the front row.





2 Rip it! Pull harder to go faster!



IMPORTANT:
Toy does not function when ripcord is
inserted into the left hand side of the car.

3

Too easy?
Make the gap bigger and take
the championship jump challenge!



Insert ripcord and
launch the back row!


Works best on hard, flat surfaces.

One vehicle included. Others shown sold separately,
subject to availability.


For use with RIPLASH RACERS™ vehicles only.

THE CHAMPIONSHIP JUMP


1 Disconnect the loop.



2 Move the loop marker and base marker to 8.





3 Reconnect the loop and launch vehicles.



Keep crashing?
Make the gap smaller and practice until you get better.


STUNT RAMP Jump through the loop!



4 / TROUBLESHOOTING

Q. Why do my cars keep crashing for no reason?

A. Make sure the tracks are connected securely and flush. Adjust track side walls at connection points as shown.



Q. My cars cannot complete the jump. What's wrong?

A. It takes skill to complete a jump. Start from 0 and try bigger jumps as you improve. Make sure the loop marker and base marker are set to the same number.

